

Lift Parts

Examine and repair switch LLPA6-6



Examine and repair switch LLPA6-2



Pushbutton switch LLPA5-1



Pushbutton switch LLPA5-2



Examine and repair switch LLPA7-4



Examine and repair switch LLPA7-5



Examine and repair switch



Limit Switch LDNR292798



Holder Screw



 $M12 \times 34mm$

 $M14 \times 40$ mm

Limit Switch LLJW58-0E



 $M10 \times 28mm$

Expand Screw





M16×120mm







Lift Electromacnt

